

REOTEMP POCKET THERMOMETER D-450

WARNING: DO NOT SUBJECT THERMOMETER TO EXTREME TEMPERATURE CHANGES

Easy to Operate: Insert stem into food or substance. An instantaneous reading will appear when update button is pressed. When update button is not engaged, the unit operates at 10 second intervals. The instrument will automatically turn to an "OFF" mode after 50 minutes of non-use. Depress the update button to resume temperature monitoring.

Easy to Clean: Wash by hand. Do not immerse head. Remove stubborn grease from stem with scouring pad or fine steel wool.

Battery Removal: Place screwdriver blade in slot of battery cover. Turn counter-clockwise until cover is removed. Replace with 1.5 volt #392 battery and screw battery door clockwise until tight.

IMPORTANT

Do not leave thermometer in food or substance for extended time. Do not leave thermometer in food while cooking. This thermometer is intended solely to test temperatures.



REOTEMP Instrument Corporation

10656 Roselle Street- San Diego, CA 92121 Phone (800) 648-7737 Fax (858) 784-0720
Email: reotemp@reotemp.com- www.reotemp.com

DP450